

# Female Performance/Elite Size Chart



## Performance

Suit Size	26	28	30	32	34	36	38	40	42	44
Junior Apparel Equivalent*	0	1/2	3/4	5/6	7/8	9/10	11/12	13/14	15/16	17/18
Apparel Equivalent	XS	XS	S	S	M	M	L	L	XL	XXL
Speedo® Team Apparel	XS	XS	S	S	M	M	L	L	XL	
Chest	31	32	33	34	35	36 1/2	38	39 1/2	41	42 1/2
Waist	23	24	25	26	27	28 1/2	30	31 1/2	33	34 1/2
Hip	33 1/2	34 1/2	35 1/2	36 1/2	37 1/2	39	40 1/2	42	43 1/2	45
Torso	55	56 1/2	58	59 1/2	61	63 1/2	66	68 1/2	71	73 1/2

## LZR Racer® Elite and LZR Racer® Pro

Suit Size	23	24	25	25 L	26	26 L	27	27 L	28	28 L	29
Body Loop	55	57	60	62	62	64	64	66	66	68	68
Chest	32	33	34	34	35	35	36	36	38	38	39
Waist	23	24	25	25	26	26	28	28	30	30	31